



## Scottoil: Ducati Sport Classic Models

Installation Guide for Ducati GT1000, Paul Smart 1000LE, Sport 1000

Note: The Dual Injector (sold separately) is not suitable for these models



Locate the vacuum – There is a vacuum point on the inlet tract, as shown below left.

Remove the screw and replace with the M5 Brass Spigot from the Scottoil kit, using some RTV Silicon Sealant on the threads to ensure an airtight seal.

Then press the Damper Elbow, part number 4, onto the spigot.



The RMV can be mounted on the frame or under the seat.

The more vertical the RMV the better and remember to avoid exhaust and engine components.

For further information, see our easy step installation guide – '**RMV Positions, General**'.



The Dispenser Assembly, shown left is routed along the underside of the Swingarm using Dispenser Mounting Sleeves, Cable Ties & Glue. **Note:** an epoxy resin (eg. Araldite) is req'd to bond the sleeves to the Swingarm.

For further information see our easy step installation guide - '**Dispenser Assemblies, General**'.

The nib should feed the sprocket between the 6 & 7 o'clock positions, with the cut face facing outwards, as shown bottom left.



Once fitted, fill and prime the system and set the adjuster knob to 'prime'.

Start the engine and turn the adjuster knob until a flow of between 1 and 2 drops per minute is achieved.

Check the condition of your chain after a ride, and then adjust as required.

Note: This is a generic image

If you have any further comments or queries, and are unable to resolve them using our website, please do not hesitate to call technical on 0141 955 1100 or email [technical@scottoiler.com](mailto:technical@scottoiler.com) for assistance. Thank you.

Scottoil Ltd. 2 Riverside, Milngavie, Glasgow, G62 6PL Tel. 0141 955 1100 Fax. 0141 956 5896 [www.scottoiler.com](http://www.scottoiler.com)

